





WIRELESS MICROPHONE RECEIVER




Connect to MIC. receiver (Rear MIC. 4)

Connect to MIC. receiver (Rear MIC. 5)




DVD PLAYER

CDG PLAYER




PC SOURCE


BGM (BackGround Music)




KP-600




Audio Cable Size XLR (M) to RCA (M)



MA-1200





MAIN SPEAKER LEFT



MAIN SPEAKER RIGHT




WIRELESS MICROPHONE RECEIVER




Connect to MIC. receiver (Rear MIC. 4)


Connect to MIC. receiver (Rear MIC. 5)



DVD PLAYER




CDG PLAYER




PC SOURCE


BGM (BackGround Music)



KP-600



EQ




Composite Video


Composite Video

Composite Video


Audio Cable Size XLR (M) to RCA (M)




MA-1200




MAIN SPEAKER LEFT MAIN SPEAKER RIGHT




SUBWOOFER
BUILT-IN POWERED SUB




Audio Cable Size XLR (M) to RCA (M)




MONO Adaptor



KP-600




MA-1200



Audio Cable Size XLR (M) to RCA (M)

If you use it indoor for area of 3,000 square feet or outdoor, we recommend you using two power amplifiers to drive the four speakers. Please refer to the next diagram for connection.



MA-1200

